




#YourGearUpgraded

"Wanna show off your hard work?
Share a picture of your completed
project with **#YourGearUpgraded**.

Who knows, it might not be
as bad as you thought"

IN-WALL POWER + CABLE MANAGEMENT KIT

Model **EGAV-CMIWP1**
OWNERS GUIDE



Confuzzled? Call the ECHOGEAR Pros:



1-855-428-2490



helpmehelpyou@ECHOGEAR.com

IMPORTANT SAFETY INSTRUCTIONS

PLEASE READ ENTIRE MANUAL PRIOR TO USE - SAVE THESE INSTRUCTIONS

YEA, THE BORING STUFF ... but read it, so you don't jack things up!

"apologies, to
all the Jacks
in the world"

⚠ CAUTION: Avoid potential personal injuries and property damage!

- Please read through these instructions completely to be sure you're comfortable with this easy install process.
- Do not use this product for any purpose not explicitly specified by manufacturer.
- Manufacturer is not responsible for damage or injury caused by incorrect assembly or use.
- If you do not understand these instructions or have doubts about the safety of the installation, assembly or use of this product, contact The Echogear Pros at www.echogear.com.


⚠ WARNING: RISK OF FIRE AND SHOCK. Do not connect the modules **01** or **02** to any other circuits or outlets.

⚠ CAUTION: RISK OF FIRE AND SHOCK. ONLY intended for use on 15 ampere branch circuits.
Do not install power supply cord **03** within wall cavity.

This product conforms to and should be properly grounded in compliance with requirements of the current National Electrical Code or codes administered by local authorities.

All electrical products may present a possible shock or fire hazard if improperly installed or used. This product may bear the mark of a Nationally Recognized Testing Laboratory and should be installed in conformance with current local and/or the National Electrical Code.

WHAT'S IN THE BOX




⚠ WARNING: DON'T FEED TO CHILDREN — This product contains small items that could be a choking hazard if swallowed.

Before starting assembly, verify all parts are included and undamaged. If any parts are missing or damaged, do not return the damaged item to your dealer; contact Customer Service. Never use damaged parts!

FREE

TOY SURPRISE
Inside Every Box



Milestone AV Technologies and its affiliated corporations and subsidiaries (collectively, "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions, or variations. Nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

©2018 Milestone AV Technologies. All rights reserved. ECHOGEAR is a Milestone brand. ECHOGEAR and the ECHOGEAR logo are trademarks of Milestone.


Milestone Global Headquarters 6436 City West Parkway; Eden Prairie, MN 55344 USA

1022064 06/18

GRAB YOUR TOOLS




Tape Measure



Pencil



Electric Drill




Phillips Screwdriver

"Phil wants his
tools back"



Paint (optional)
Surfaces are paintable
to match your decor


❗ VERIFY WALL COMPATIBILITY



This Cable Kit is designed to fit
into both interior and exterior walls
constructed with:

❗ **Minimum Space into Wall:** 3 in.


❗ **Minimum Drywall Thickness:** 1/2 in.



NOTE: Walls
with blown-in
type insulation
may require
removal of some
insulation inside
the cavity.

❗ VERIFY TV PLUG FIT




BEFORE DRILLING ANY HOLES:
Make sure your TV plug fits in the
upper module **01**.



"size DOES matter"

STEP 1


A Assemble Hole Saw



MAKE SOME HOLES


B Drill Holes


TIP: Drill the top hole
BEHIND your TV.




STEP 2

ROUTE CABLES

**TIP:** Use a fish tape, to pull the cables through the wall.






STEP 3

INSERT MODULES IN WALL

**NOTE:** The gaskets can be removed for larger cables.






STEP 4

SECURE MODULES

**DO NOT** loosen the screws







STEP 4

POWER UP

TV and Accessories




Power Cord




REMOVAL


A Unplug power cords



B Remove trim plate



C Turn screws to remove module



Loosen ONLY enough to remove module.

