





#YourGearUpgraded

## SOUND BAR MOUNT

Model **EGSB1**

INSTRUCTION MANUAL




# IMPORTANT SAFETY INSTRUCTIONS. READ ENTIRE MANUAL PRIOR TO USE. SAVE


## YEA, THE BORING STUFF ...

*... but read it, so you don't jack things up!*

- ☐ Your TV, soundbar, soundbar mount, and any accessories you plan to install DO NOT EXCEED the specified weight limit of your TV or TV wall mount.
- ☐ You read and understand these directions.
- ☐ You refer to the documentation that came with your sound bar, your TV and your TV wall mount for additional guidance.
- ☐ You have the tools needed for installation.
- ☐ You CANNOT use this product if your TV mount's interface bracket: includes built-in/integrated spacers (Pic 1), or the mounting holes/slots are greater than 11mm [.43 in.] (Pic 2).




**Pic 1**



**Pic 2**

## ⚠ **WARNING:**

- ▶ This soundbar mount is only designed for use with TV wall mounts that meet third party safety certifications (UL Certified).
- ▶ This soundbar mount is **ONLY** designed to mount **below** the television (Pic 3).
- ▶ This soundbar mount is designed to be installed and utilized only as specified in this manual. The manufacturer is not responsible for improper assembly, use, or handling of this product.
- ▶ For wall mounted TVs: Your wall must be capable of supporting five times the weight of your TV, TV mount, and soundbar combined.
- ▶ Failure to follow these instructions could result in an unstable situation that may result in property damage or personal injury.



*Don't get it?*  
Call The **ECHOGEAR Pros**  
**1-855-428-2490**

# WEIGHT RESTRICTIONS

**Weight Limit  
for EGSB1**

**15 lb  
(6.8 kg)**

**DO NOT EXCEED 15 lbs. (6.8 kg)**  
for this Soundbar Mount.

*"You can think about it ... but doooooon't do it."*


**TOTAL Weight Limit for Your TV Mount/Stand** – "test your math skills"

**⚠ CAUTION:** Avoid potential personal injuries and property damage!  
The weight of your TV/ this soundbar mount/your soundbar/any accessories,  
**MUST BE LOWER** than the maximum weight rating of your TV mount.

**See your TV mount's manual for maximum weight allowed.**



Soundbar  
Mount



Your  
Soundbar



ANY Other  
Accessories



Your TV

Maximum  
weight for Your  
TV Mount/stand

**2 lbs.  
(0.9 kg)**

**+**  
(plus)

**lbs.  
( kg)**

**+**  
(plus)

**lbs.  
( kg)**


**+**  
(plus)

**lbs.  
( kg)**

**=**  
(equals)

**MAX  
TOTAL  
WEIGHT**

# GRAB YOUR TOOLS




**Phillips Screwdriver**

*"Give it back to Phil  
when finished"*



**Level**




**3<sup>rd</sup> Party Certified  
TV stand or Wall Mount\***

*"UL Listed  
... for safety sake!"*

\*The TV mount styles illustrated will vary, though the install procedures are the same.

# WHAT'S IN THE BOX

**⚠ WARNING:** *"DON'T FEED TO CHILDREN"* — This product contains small items that could be a choking hazard if swallowed. Before starting assembly, verify all parts are included and undamaged. If any parts are missing or damaged, do not return the damaged item to your dealer; contact Customer Service. Never use damaged parts!

 **NOTE:** Not all hardware included will be used.

## PARTS FOR STEP 1.1



Vertical  
Soundbar  
Bracket

**01** x 2

Left Soundbar  
Bracket



**02** x 1

Right Soundbar  
Bracket




**03** x 1

Knob  
Washer



**04** x 2 of 6 \*


Knob



**05** x 2

\* also used in another step


## PARTS FOR STEP 1.3



M4/M5  
Washer




**08** x 2 of 4 \*




Knob  
Washer



**04** x 2 of 6 \*




Keyhole  
Screw



**09** x 2


Wing  
Nut







**10** x 2

\* also used in another step

## PARTS FOR STEP 2.3



 **NOTE:** These extra screws and washers are provided if you need to modify your screw length.



**Knob  
Washer**



**04**  
x 2 of 6 \*

**M4/M5  
Washer**



**08**  
x 2 of 4 \*

**M6/M8  
Washer**



**14**  
x 2

\* also used in another step

**You're ready!**  
**LET'S DO THIS!**




## STEP 1

## INSTALL BRACKETS ON YOUR SOUNDBAR

### STEP 1.1


### Assemble Soundbar Brackets




## STEP 1.2

## Orient the Brackets For Your Sound Bar

For **Wide** Hole Spacing



For **Narrow** Hole Spacing




## STEP 1.3

## Secure the Brackets on Your Sound Bar

Look at the mounting holes on the back of your soundbar to determine your install method **A**, **B** or **C**.



**A:** Threaded inserts → 




**B:**

Key hole slots




*"Old-timey key shape"*


## ASSEMBLE



**INSERT,  
LIFT UP,  
then  
TIGHTEN**



**C:** Rivets with a separate hanger bracket → *"If supplied with your soundbar"*



**ASSEMBLE**

Soundbar  
Hanger

09

02 03

10

(Back of hanger)

**TIGHTEN**

## STEP 2


## INSTALL YOUR SOUNDBAR TO YOUR TV

### STEP 2.1


**Prep Your TV** (if mounted on a wall or stand)

**! IMPORTANT!** Save ALL hardware you remove for use in later steps.


**a. UNPLUG**  
all cables from  
your TV.



**b. DISMOUNT**  
your TV from the  
wall or floor mount.






**c. REMOVE**  
the TV bracket(s)  
from your TV.



## STEP 2.2

# Adjust Soundbar to Your TV (VESA) Hole Pattern


**SLIDE** ..... or ..... **ROTATE** ..... or... **SWITCH** and **ROTATE**



## STEP 2.3

## Fasten Your Soundbar to Your TV

Follow your TV mount or stand's installation manual to install your TV brackets onto your TV.

 **NOTE:** Sound bar brackets **01** AND spacers **11** install BETWEEN your TV and TV brackets.  
*“like a sammich”*

 **NOTE:** Extra screws **06**, **12** and **13** and extra washers **04**, **08** and **14** are provided, if needed for better fit (TV screws are too short - or too long).


**Need longer fasteners? Call The ECHOGEAR Pros 1-855-428-2490**

**⚠ CAUTION:** Verify adequate thread engagement with your screw/washer/spacer combination AND all brackets.

- Too short will not hold the TV.
- Too long will damage the TV.







## TV Brackets

(From your TV mount/  
stand -- Style will vary)

## TV Bracket Hardware


(From your TV mount/stand)

**11**

Extra washers  
**08** or **14** can be  
stacked if screws  
are too long

## Sound Bar Assembly

(Style will vary)



## STEP 3

## HANG YOUR TV/SOUNDBAR ASSEMBLY

Follow your TV wall mount or stand installation manual to hang your TV assembly and finish your installation.


### ! IMPORTANT!

Make sure ALL fasteners are tightened before continuing.

### ! CAUTION:

DO NOT overtighten the fasteners — tighten only until snug.

*“Easy there Popeye”*



“Wanna show off your hard work? Share a picture of your completed project with **#YourGearUpgraded**.  
Who knows, it might not be as bad as you thought”

## ***Confuzzled?* Call the ECHOGEAR Pros:**

 1-855-428-2490       [helpmehelpyou@ECHOGEAR.com](mailto:helpmehelpyou@ECHOGEAR.com)

Milestone AV Technologies and its affiliated corporations and subsidiaries (collectively, “Milestone”), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions, or variations. Nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

©2016 Milestone AV Technologies. All rights reserved. ECHOGEAR is a Milestone brand. ECHOGEAR and the ECHOGEAR logo are trademarks of Milestone.

Made in China.

Milestone Global Headquarters • 6436 City West Parkway • Eden Prairie, MN 55344 USA

6901-602117 00