




#YourGearUpgraded

# FULL MOTION TV WALL MOUNT

Model **EGLT1**

INSTRUCTION MANUAL



**IMPORTANT** SAFETY INSTRUCTIONS. **READ** ENTIRE MANUAL PRIOR TO USE. **SAVE** THESE INSTRUCTIONS

**YEA, THE BORING STUFF ... *but read it, so you don't jack things up!***

Please read through these instructions completely to be sure you're comfortable with this easy install process. Also check your TV owner's manual to see if there are any special requirements for mounting your TV.

If you do not understand these instructions or have doubts about the safety of the installation, assembly or use of this product, **contact The Echogear Pros at 1-855-428-2490.**

**⚠ CAUTION: Avoid potential personal injuries and property damage!**

- ▶ This product is designed for use in wood stud, solid concrete, and concrete block walls - DO NOT install into drywall alone
- ▶ The wall must be capable of supporting five times the weight of the TV and mount combined
- ▶ Do not use this product for any purpose not explicitly specified by manufacturer
- ▶ Manufacturer is not responsible for damage or injury caused by incorrect assembly or use

## WEIGHT RESTRICTIONS



Your TV (including accessories)  
**CANNOT EXCEED 125 lbs.  
(57 kg) for this mount.**

*"You can think about it ...  
but doooooon't do it."*

If your TV weighs more, this mount is NOT compatible.  
Visit [echogear.com](http://echogear.com) to find a compatible mount.


**⚠ CAUTION:** DO NOT exceed the maximum weight indicated. This mounting system is intended for use only with the maximum weights indicated. Use with products heavier than the maximum weights indicated may result in collapse of the mount and its accessories, causing possible injury.

# VERIFY YOUR WALL CONSTRUCTION

**⚠ CAUTION:**


**DO NOT  
install into  
drywall alone**

*... unless you WANT to  
watch your TV fall and  
crash onto the floor.*



wood  
studs?

**Perfect!  
Good to Go**



**UUUUHHH?!?  
Unsure?**

**Contact The Echogear Pros  
at 1-855-428-2490 or  
[www.echogear.com](http://www.echogear.com)**


## GRAB YOUR TOOLS




**Stud  
Finder**




**Awl**



**Tape  
Measure**



**Pencil**



**Level**




**Phillips  
Screwdriver**

*"Give it back  
to Phil when  
you finish"*



**Electric Drill**



**7/32 in.  
(5.5 mm)  
for wood**



**1/2 in.  
(13 mm)**  
**Socket  
Wrench**

We're driven to give DIYers an awesome install experience. We stand behind everything we make because you deserve the best entertainment experience without sacrificing quality and spending your whole paycheck.

Guess what? We'll help you through the entire process, too.

Why? Because we like to help and it's our passion to provide authentic service. We won't leave you hanging, no matter what.

Our U.S. based Echogear Pros answer the phone in all days ending in Y. That means availability to try and stump our expert staff 7 days a week.

Call us if you...

- 1 Have any questions before, during, or after install.
- 2 Need different hardware to fit your TV model.
- 3 Just need someone to chat with. We're here for you.






# WHAT'S IN THE BOX

**⚠ WARNING:** DON'T FEED TO CHILDREN — This product contains small items that could be a choking hazard if swallowed. Before starting assembly, verify all parts are included and undamaged. If any parts are missing or damaged, do not return the damaged item to your dealer; contact Customer Service. Never use damaged parts!



**📄 NOTE:** Not all hardware included in this kit will be used.

## STUFF FOR STEP 1

### 01 TV Screws (qty. 4 each) [Only one size fits your TV]




### 02 Washers (qty. 4 each)



### 03 Spacers [If necessary]



### TV Brackets






**04**  
qty. 1


**05**  
qty. 1

## STUFF FOR STEP 2

### Wall Plate Sections




### Connection Plate Screws



M5 x 8mm

### Washer (For Lag Screw)



# STEP 1

# ATTACH THE TV BRACKETS TO YOUR TV

## STEP 1.1


## Select TV Screws

Only one screw size fits your TV.


M4







M6



M8





*"Suggested uses for the extra screws:  
board game pieces,  
industrial jewelry,  
sweet corn holders,  
musical instruments –  
like maracas or  
'monsoon' sticks,  
stocking stuffers,  
currency (not most  
countries) ..."*



## STEP 1.2



## Select Spacers (if needed)





**Flat TV**  
Spacer not necessary



**Flat TV with:**  
Inset Holes      Cable Interference




**Rounded TV**




## STEP 1.3

## Secure the TV Brackets



**⚠ CAUTION:** Ensure the TV brackets **04** and **05** are EQUALLY CENTERED on your TV AND securely fastened in place.


### a No Spacer



Alternate  
Spacer  
setups



### b With Spacer




## STEP 2

## INSTALL THE WALL PLATE

### ⚠ CAUTION:

Avoid potential personal injuries and property damage!




Drywall covering the wall must not exceed 5/8 in. (16 mm).

Minimum wood stud size: nominal 2 x 4 in. (51 x 102 mm) actual 1 1/2 x 3 1/2 in. (38 x 89 mm).

### STEP 2.1

### Assemble Wall Plate



## STEP 2.2

## Find a Stud

**X-Ray  
Specs  
sold  
separately**

Use a stud  
finder ...

... and/or verify  
the edges with  
an awl or a  
small drill bit.

"favorite  
pokey device"

## STEP 2.3

## Mark the Location


"Come on ...  
level with me"

06

07


## STEP 2.4

### Drill Holes



## STEP 2.5

### Secure Wall Plate




**⚠ CAUTION:** Avoid potential personal injury or property damage! All four lag screws **09** MUST BE firmly tightened to prevent unwanted movement of the wall plate assembly.

## STEP 3

## HANG YOUR TV

### STEP 3.1

### Tilt Adjustment



Now is a good time to adjust the angle position of your TV, because you may need to remove the TV if you want to adjust it later.

**! IMPORTANT:** Tighten knobs **(K)** before hanging.


### STEP 3.2

### Hang Your TV



**HEAVY!** You may need assistance with this step.



*"Ask that friend of yours that yammers on about CrossFit"*





## STEP 3.3


## Secure Your TV



**⚠ CAUTION:** Avoid potential personal injury or property damage! Locking screws **S** MUST BE firmly tightened BEHIND THE WALL PLATE **06** - **07** to secure the TV in place.


# ADJUSTMENTS

## TILT



 **TIP:** You may need to remove your TV if your TV is so ginormous and you can't reach the knobs (K).

## SIDE-TO-SIDE




## REMOVE YOUR TV



**HEAVY! You may need assistance with this step.**

*"Don't be a hero!"*





“Wanna show off your hard work?  
Share a picture of your completed project  
with **#YourGearUpgraded**.  
Who knows, it might not be as bad as you thought”

## ***Confuzzled?* Contact the ECHOGEAR Pros:**



1-855-428-2490



helpmehelpyou@ECHOGEAR.com



ECHOGEAR.com

Milestone AV Technologies and its affiliated corporations and subsidiaries (collectively, “Milestone”), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions, or variations. Nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

©2018 Milestone AV Technologies. All rights reserved. ECHOGEAR is a Milestone brand.

ECHOGEAR and the ECHOGEAR logo are trademarks of Milestone.

Made in China.

Milestone Global Headquarters • 6436 City West Parkway • Eden Prairie, MN 55344 USA

6901-602255 00